













Montážní návod - BAT NET PERF

A		5
B		1
C		1
D		1
E		1
H		2

G	 M6x25mm	6
G1	 M8x20mm	4
G2	 M5x10mm	1
I		1
L	 5#	1
L1	 5#	1

